


When ordering parts from this catalog please furnish the page number, code number and machine serial number.

CODE NO.	DESCRIPTION	QTY
6-1	Manifold, Wheel Box	1
6-2	Spacer, Manifold	2
6-3	Plate, Long Clamp	12
6-4	Plate, Short Clamp	6
6-5	Silencer	1
6-6	Blower	1
6-7	Bracket, Tie-In	1
6-8	Platform, Blower	1
6-9	Duct Run, Blower	1
6-10	Duct, Transition	1
6-11	Wheel Box	Ref
6-12	Plate, Slide	6
6-13	Hinge, Slide	6
6-14	Handle, Slide	6
6-15	Holder, Slide	6
6-16	Bushing, Drill	24



# VACUUM SYSTEM